
Dimensions



Returns & Faulty Items

- If any problem is encountered during or after installation, please call the ALL LED technical department to get the problem resolved as soon as possible.
- Please do not just return the item to the outlet you purchased it from, as you are only entitled to a replacement or refund after the unit has undergone testing and the unit has been confirmed as having a manufacturing defect/fault. Your statutory rights are not affected.
- The manufacturer will not be deemed liable or held responsible for any damages caused by faults or manufacturing defects that may be present in any of its products or the misuse or incorrect installation of this device. Please refer to our troubleshooting guide for further information.
- All goods are supplied under the terms and conditions of All LED LTD, a copy of which may be obtained upon written request.





ALL LED LTD 42 Sedgwick Road, Luton, LU4 9DT

www.allledgroup.com sales@allledgroup.com Tel: +44 (0)208 841 9000

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice

Environmental Protection












INSTALLATION GUIDE Smart Remote RGBW

AiQ/RGBW/RMT



Note: This remote supports 4 groups for binding 30 lighting devices maximum. Also enables control of DIM, CCT, RGB, RGBW and RGB+CCT lighting devices.

Product Data

Code	AiQ/RGB/RMT
Protocol	Zigbee 3.0
Operation Voltage	6V
Battery Type	CR2032 x 2
Transmission Frequency	2.4 GHz
Transmission Range (Free Field)	30 m
Dimension	137x45x13mm
Protection Grade	IP20




Quick Install Guide


To be able to use a remote with your smart home hub and intelligent lighting follow (1 and 2). If you would like to use your remote directly with your intelligent lighting without a hub, follow instructions (2).

1) Connecting Your Remote to Smart Home Hub

Note: Before the first use, please remove the protective film on the battery.




2) Connecting Your Remote To Intelligent Lighting




Factory Reset Remote


2



Removing Intelligent Lighting From Your Remote



How To Save And Recall Scenes



Recall The Saved Scenes

3

Step 1: Short press button S1-S7 to recall a saved scene for each individual group at the same time.